



DIY PROJECT:

RESURFACING DRIVEWAY

INSTRUCTIONS:

1. PREPARE THE SITE:

Repair cracks with appropriate Cemix® mortar or epoxy.

2. PREPARE THE SURFACE

Water blast the driveway. Ensure the surface is cleaned removing any and all surface coatings and loose material back to bare concrete.

3. MIXING PRODUCT:

Per the instructions on the packaging, using an electric drill, mix the Cemix® Concrete Resurfacer with the suggested quantity of water.

4. APPLICATION:

With a steel squeegee, apply the first coat evenly across the substrate surface. When dry, apply a mist of water as a primer. Apply a second coat of Cemix® Concrete Resurfacer at this stage.

5. TIPS:

This is a very fast drying product, Brush out any trowel lines or ridges immediately with a trowel or brush. Visit www.cemix.co.nz to watch the video tutorial.



BEFORE



AFTER



CONCRETE RESURFACER

THE FAST, EASY & COST
EFFECTIVE SOLUTION FOR
TIRED LOOKING CONCRETE

WHAT YOU WILL NEED:



STEEL
SQUEEGEE



WATER
BLASTER



WATER



MIXER /
ELECTRIC DRILL



BRUSH

CEMIX

WWW.CEMIX.CO.NZ // 0800 ASK CEMIX //