



Sep 2022 | Page 1



# **PLIMORTAR**

# **POWDERED PLASTICISER FOR MORTAR**

**AVAILABLE SIZE: 15KG** 



NOTE: Due to updates in progress, packaging may vary.

#### **DESCRIPTION:**

CEMIX® PLIMORTAR is a powdered plasticiser, designed to improve the workability and adhesion of mortar.

#### **TYPICAL USES:**

CEMIX® PLIMORTAR can be used as an air entraining additive for mortar, removing the need for adding lime to the mix.

# **ADVANTAGES:**

- · Improves workability and bond strength
- Allows for quicker application

### **DOSAGE:**

25g per kg of cement

#### PREPARATION:

Refer to the manufacturer's recommendations for the exterior use plaster or mortar being used.

#### MIXING:

1. Add the product directly to the mix during mixing. Use 25g of product per kg of cement.

**Note:** Do not aerate the mixture by stirring over vigorously or for too long. In general, a maximum of 2 minutes is recommended. Accurate measuring is essential as too much product can weaken the mix - use less product rather than more.

# **APPLICATION:**

Refer to the manufacturer's recommendations for the exteriour use plaster or mortar being used.

#### **CLEANING:**

Clean tools with water immediately after use.

#### STORAGE & SHELF LIFE:

Up to 12 months when stored in the original, unopened packaging, in a dry place at 23°C and 50% relative humidity.

# LIMITATIONS:

Accurate measuring is essential as too much product can weaken the mix - use less product rather than more.

If your project requires Building Consent, please email info@cemix.co.nz about the suitability of this product before use.

Read Label Before Use. Keep out of reach of children. If medical advice is needed, have product container or label at hand.

# **WARNING**

# **HAZARD STATEMENTS:**


- Causes skin irritation
- · Causes serious eye irritation

# **SAFETY INSTRUCTIONS:**

Wear protective gloves/protective clothing/eye protection/face protection.

#### **RESPONSE:**

Take off contaminated clothing and wash before reuse. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.



Sep 2022 | Page 2

# **PLIMORTAR**

If eye irritation persists: Get medical advice/attention. IF ON SKIN: Wash with plenty of soap and water. If skin irritation occurs: Get medical advice/attention.

#### **INGREDIENTS:**

Bentonite, CAS: 1302-78-9, 98-99%

Calcium aluminate cement, CAS: 65997-16-2, 1-1.2%

#### **DISCLAIMER:**

Please Note: Recommendations and advice regarding the use of this product are to be taken as a guide only. Other than as appears on this product's packaging, CEMIX® PRODUCTS LTD does not give any warranty expressed or implied as to suitability for any particular use. For all advice concerning the use or suitability of this product for a particular application, please contact CEMIX® PRODUCTS LTD. If this product is defective, please contact the merchant the material was purchased from or CEMIX® PRODUCTS LTD, who will refund or replace it at no cost, in accordance with the requirements of the Consumer Guarantees Act.

### **SCAN THE QR CODE FOR MORE INFORMATION**



# **CEMIX® PRODUCTS LTD**

19 ALFRED STREET ONEHUNGA 1061 AUCKLAND NEW ZEALAND 0800 ASK CEMIX | +64 09 636 1000 WWW.CEMIX.CO.NZ



Twitter/CemixNZ



Facebook/CemixNz



Pintrest/CemixNZ



YouTube/CemixVideos

